


Installation Instructions for Flexible Beam Straps

1.



Draw a light pencil line perpendicular to the center of the beam strap.

2.



Lay the strap along the beam. Make sure that the straps three bolt heads are even on the top of the beam.

Use a pencil to mark your trim line and cut the strap along the trim line with scissors to fit to the beam.

3.



Apply a bead of adhesive to the back of the strap.

4.




Align the center of the strap with the marks made in Step 1. Press firmly on the strap working from the center up each side to ensure good contact between the adhesive and the beam.

NOTE: Use finishing nails to secure the strap to the beam to allow the adhesive to set.

Unfinished Beam Program
Create your own color
Simply make your selection from the many gel stain finishes that best suits your room.

Additional Accessories

- Single and Double Straps
- Brackets
- Touch-Up Stain



For our full selection of Faux Wood Beams and Accessories visit us online at www.outwater.com