

# Fluted Wall Cladding: Ceiling Installation



**Step One:** Install the joists with a nail gun. The joist spacing is 13-3/8" - 15-3/4".

## Required Materials & Tools



Fluted Wall Panel



Joist



Clip  
(Sold Separately)



Circular Saw



Nail Gun



## Step Two:

Position the Fluted Panel near the bottom of the joist.

# Fluted Wall Cladding: Ceiling Installation



**Step Three:** Attach the panel to the ceiling with the clip and nail gun.



**Step Five:** The second panel is now joined.



**Step Four:** Attach the next panel into the card slot on first.



**Step Six:** Continue adding panels until the installation is complete.