



Drill holes into the door with a $\frac{3}{8}"$ drill bit. Holes should be spaced $11\frac{13}{16}"$ apart and $2\frac{3}{8}"$ from the edge of the door. Refer to the above diagram to install the pull.

Outwater Industries, Inc. assumes no liability for improper installation.